

Bass amplification
Taurus
Efx

Vechoor

multi-chorus



1. Input "mono-jack"
2. Output "stereo or mono-jack", or you can use standard reducing plug as shown below.
3. Power supply DC 12V/100mA. [max power consumption 60mA]
4. **A-NORMAL-B** - mode switch Flange Modern A - Chorus - Flange Modern B.
5. **DEPTH** - chorus depth modulation knob
6. **SPEED** - speed modulation knob
7. **DETUNE** - detune modulation knob.
8. **ENHANCER** - extended polyphony low frequency range level knob. ENHANCER is modified only by DETUNE knob.
9. Footswitch - if it's turned off true-bypass is active on mono channel and in stereo mode right channel is turned on "active bypass mode".
10. CHORUS effect-mix switch - only in custom version Vechoor - C available : "A" mode - gentle chorus [30% mix]. "B" mode - optimal chorus [50% mix]
In standard version effect-mix fixed in optimal mode 50% mix.
11. Power led.